



Comparison of waters and sediments of Kupa River and Rječina River rising under the same mountain range, but belonging to two distant watersheds (North-western Croatia)

Stanislav Frančišković-Bilinski (1), Vlado Cuculić (1), Halka Bilinski (1), Philipp Stadler (2), and Hermann Häusler (2)

(1) Ruđer Bošković Institute, Division for Marine and Environmental Research, POB 180 HR-10002 Zagreb, Croatia; francis@irb.hr, (2) University of Vienna, Faculty of Earth Sciences, Geography and Astronomy, Department for Environmental Geosciences, Althanstraße 14, 1090 Vienna, Austria; philipp.stadler@gmx.at

This work presents first complementary geochemical and stable isotope investigations of Risnjak Mountain karstic aquifer system in north-western Croatia. This aquifer is an important source of drinking water for both countries Croatia and Slovenia. The two main rivers, namely the Kupa River and the Rječina River discharge the same mountain range, but belong to two different watersheds. Their springs are only 22 km apart, and located in scarcely populated areas. Kupa flows through limestones and dolomites in National Park Risnjak until it meets its largest tributary Cabranka. Rječina flows first through flysch and carbonates before it enters the Adriatic Sea. At its lower course it flows through the densely populated town of Rijeka.

For effective management of water resources the baseline data were collected. Sediment fraction $<63 \mu\text{m}$ was analyzed by ICP-MS on 52 elements. The values were compared with the existing sediment quality criteria. Continuous monitoring of Cr, Zn, As, Ba and Pb was recommended within the National Park Risnjak. Physico-chemical parameters (pH, electrical conductivity, dissolved oxygen and temperature) were measured in the field. Waters were analyzed in laboratory. Toxic elements (Cu, Cd, Pb and Zn) were determined by differential pulse anodic stripping voltametry (DPASV).

To understand the hydrodynamics of the karst groundwater system in Western Croatia detailed hydrogeologic investigations have been performed in the Rijeka catchments by B. Biondić (2000), and in the Kupa catchments by R. Biondić (2003). In addition Kapelj et al. (2002) and B. Biondić et al. (2006) investigated the isotopic composition of several springs in the Kupa- and Rječina catchments. To get a more detailed insight to hydrological processes in the drainage basins of Kupa River and Rječina River, and to compare both catchments of the Gorski Kotar, samples of some main springs and riverine waters were taken for stable isotope analysis. For the interpretation of isotope characteristics of precipitation in Croatia we refer to the comprehensive study of Vreča et al. (2006). Stable isotope composition was determined in waters during low and during high water conditions. Environmental isotopes of samples were measured at the University of Vienna, Department for Environmental Geosciences. The used set up of a Picarro Inc. Isotopic Water Analyzer combined with a CTC HTC-Pal autosampler (LEAP Technologies) is similar to the one described by Gupta et al. (2009). The Picarro "Cavity Ring-Down Spectroscopy (CRDS)" uses a near-infrared laser to define $\delta^{18}\text{O}$ and $\delta^2\text{H}$ stable isotope ratios out of liquid water samples (Picarro Inc.). CRDS is a direct absorption technique (Berdén et al., 2001) that offers results for pure water samples highly comparable in precision with classical mass spectroscopy (Brand et al., 2009).

As in karstified regions such as Gorski Kotar the area of the hydrogeological catchments mostly exceeds that of the hydrological catchments, and because karst aquifers often are overlain by nearly impermeable formations, the time delay of discharge from major karst aquifers, and their stable isotope contents can hardly be interpreted without regular sampling of numerous groundwater sources. We conclude that the aquifer of Risnjak karstic mountain region contains water within drinking water quality standards. Continuous monitoring is suggested, especially of the Kupa Spring in National Park Risnjak and of the Zvir Spring in Rijeka due to some higher concentrations of trace elements, despite the fact that they are below MDK values.

References:

BERDEN, G., PEETERS, R. and G. MEIJER (2001): Cavity ring-down spectroscopy: Experimental schemes and applications [Review], *International Reviews in Physical Chemistry* 19 4, 565-607.

BIONDIĆ, B., BIONDIĆ, R. and S. KAPELJ (2006): Karst groundwater protection in the Kupa River

catchment area and sustainable development, *Environmental Geology*, 49, 828-839.

BIONDIĆ, B. (2000): Karst groundwater protection: The case of the Rijeka Region, Croatia.- *Acta carsologica*, 29/1, 2, 33-46, Ljubljana.

BIONDIĆ, B., BIONDIĆ, R. and S. KAPELJ (2006): Karst groundwater protection in the Kupa River catchment area and sustainable development. *Environmental Geology*, 49, 828-839; doi: 10.1007/s00254-006-0178-4.

BIONDIĆ, R. (2003): Hydrogeology and protection of the Kupa River spring catchment area.- Unpublished report.

BIONDIĆ, R., BIONDIĆ, B., KAPELJ, S. and J. RUBINIĆ (2008): Hydrogeological research of the Croatian part of the transboundary aquifers (HR-SI) between Kvarner Bay and Trieste Bay. Workshop on the protection of groundwater as a source of drinking water in karst areas, April 14-15, 2008, Malinska, Croatia.

BIONDIĆ, R., BIONDIĆ, B. and H. MEASKI (2010): The conceptual hydrogeologic model of the Plitvice Lases.- *Geologica Croatica*, 63/2, 195-206, 16 fig., 1 tab., doi: 104154/gc.2010/17, Zagreb.

GUPTA, P., NOONE, D., GALEWSKY, J., SWEENEY, C., and B. H. VAUGHN (2009): Demonstration of high-precision continuous measurements of water vapor isotopologues in laboratory and remote field deployments using wavelength-scanned cavity ring-down spectroscopy (WS-CRDS) technology. *Rapid Communications in Mass Spectrometry* 23, 16, pp. 2534-2542.

PICARRO INC. www.picarro.com, last visited December 20th 2010.

VREČA, P., BRONIĆ, I. K., HORVATINČIĆ, N. and J. BARESIĆ (2006): Isotopic characteristics of precipitation in Slovenia and Croatia: Comparison of continental and marine stations, *Journal of Hydrology*, 330, 457-469.